


ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler
CANAAN FLOOR LAMP



IMPORTANT SAFETY INSTRUCTIONS:


* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

Do NOT alter the plug.

* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptical.

* Switch power off and remove plug from the wall outlet before replacing the bulb.

* This lamp is UL rated for dry locations.



ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Remove finial (A) from shade riser (D). Thread shade riser (D) onto socket housing (E).
3. Place shade (C) onto shade riser (D).
4. Place diffuser (B) onto shade riser (D).
5. Thread finial (A) back onto shade riser (D) to secure placement of shade and diffuser.
6. Insert two 100W Max. Type A, medium base bulbs into the sockets.
7. Insert polarized plug (F) into wall outlet.
8. Use pull chains to control power to the lamp.

To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

